




Måttbild på mätarskåp FQI125 och FQI163 (Infällda).




Mått (mm)	A	B	C	D	E
FQI125/FQI163	795	545	710	620	170

Hålstorlek	1	2	3	4	5	6	7	8	9
mm	30x55	45x110	ø 55	ø 34	ø 30	ø 18	ø 25	ø 21	ø 17




Mått	A	B	C	D	E	F
FQU125/FQU163	810	780	750	125	585	220


Måttbild på mätarblock och tavlor QM och QT.



QT25



QT63



Mätarblock	Antal mätarplatser	Yttermått (mm)		
		B	H	D
QM22	4	430	1206	62
QM23	6	430	1556	62
QM32	6	640	1206	62
QM33	9	640	1556	62